

Under the Sink Grease Trap FSE Requirements

- Must have vented flow restrictor connected to the inlet side of the trap.
- There must be sufficient clearance above the trap to facilitate proper cleaning and maintenance duties. This includes but is not limited to removal of internal baffle(s) for cleaning and maintenance.
- Must be cleaned every 30 days or less.
- If the trap exceeds 25% capacity, the cleaning frequency must be increased to bi-weekly.
- Employees can clean and maintain grease traps.
- A log with the following information must be maintained on-site for three years:
 1. Date of cleaning
 2. Approximate gallons of grease removed every cleaning
 3. Disposal location (i.e. spill proof container and place in dumpster)
- A certified grease waste hauler must certify grease trap once annually.